

# MULTIPURPOSE-MOUNT ACCESSORY BRACKET INSTRUCTIONS

## THANK YOU FOR PURCHASING AN MSW® ACCESSORY BRACKET.

**▲ WARNING:** CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to: [www.mswbike.com/safety](http://www.mswbike.com/safety).

## COMPATIBILITY AND INTENDED USE

The MSW Multipurpose-Mount Accessory Bracket can be mounted to any tube on your bike with a diameter between 20 and 34mm, such as handlebar, seatpost, or frame.

## TOOLS REQUIRED

3 and 4mm hex wrenches

## INSTALLATION

1. Once you've identified your desired location, completely remove the 3mm hex bolt from the round part of the bracket and attempt to fit it to the tube without using any shims.
2. The ideal fit will grip the tube snugly and leave 1–5mm between the two halves of the round part of the bracket. Select the shim or combination of shims that give this fit.
3. Once you've achieved the ideal fit, thread the 3mm hex bolt back through the bracket until finger tight.
4. Finalize the position of the accessory mount and use a 3mm hex wrench to tighten the hex bolt until snug and the bracket no longer rotates freely around the tube.
5. To rotate the bracket, loosen the 3mm hex bolt in the center of the bracket, rotate bracket to desired position, and tighten bolt.

## ONGOING MAINTENANCE

Periodically wipe down your MSW Accessory Bracket with a damp cloth. Inspect the plastic for signs of cracking and hardware for signs of corrosion. If you find cracks or corrosion, please replace the bracket.

## LIMITED 2-YEAR WARRANTY

MSW warrants this new MSW product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of MSW, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the MSW product and is not transferable.

In no event shall MSW be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the MSW product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended use with or compatible with MSW products

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.