



MSW PORK CHOP RACK RCR-200		
Item No.	Description	Qty.
1	RCR-200 Rack	1
2	U-Mount & Strut Sub-Assembly	2
3	M5 Washer, stainless steel	6
4	M5 Bolt, stainless steel	6
5	Swivel Bolt	2
6	Strut	2
7	End Cap	2
8	M5 x 12mm Washer	2
9	M6 Locking Nut, stainless steel	2

Thank you for your purchase! At MSW we believe having essential accessories makes a good bike ride great—we hope you enjoy the increased cargo capacity and opportunities the MSW Pork Chop Rack can provide.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to: www.mswbike.com/safety.

COMPATIBILITY AND INTENDED USE

MSW racks are compatible with bicycle frames that have threaded mounting points at the rear axle, and can accept bolts on mounts near the seatpost that are already integrated into the frame design, or can safely accept rubber-coated clamps around the frame. **Carbon fiber frames are not compatible with MSW Racks. MSW Racks are intended for recreational riding, not aggressive or stunt riding.**

The MSW Pork Chop Rack is compatible with most 700c cantilever and disc brake bicycles; check with your dealer.

⚠ WARNING:

- The maximum weight limit for the Pork Chop Rack is 40 lb
- This rack is only intended for use on the rear of a standard bicycle, do not use on any other vehicles
- Do not modify the rack or attempt to use as a front rack
- Bicycle may behave differently (particularly steering and braking) when the rack is loaded
- Make sure to position reflectors and lamps securely so that they are not obscured when items are attached or loaded to the rack
- Make sure to evenly distribute loads on all sides of the rack
- MSW racks are not designed to carry live cargo
- Only use the hardware included with your rack. Do not substitute with any other hardware

TOOLS AND SUPPLIES

Torque wrench that measures in Nm

4mm Allen wrench

8mm open-end wrench

INSTALLING THE RACK

Refer to technical drawings for appropriate hardware installation.

1. Loosely attach rack to lower rack mounts on bicycle using appropriate bolts and washers as shown in product diagram on page 1 (figure 1).



Figure 1

2. Loosely attach the rack struts to the rack (figure 2).



Figure 2

3. Loosely attach the rack struts to the threaded upper mounts on the bicycle or to rubber-coated clamps using two bolts and two washers (figure 3).



Figure 3

4. Extend rack struts until platform of rack is parallel to the ground.
5. When the rack is level, tighten the bolts that secure the rack and struts directly to the bicycle frame, and all the hardware that attaches the struts to the rack to 4–5Nm.

ONGOING MAINTENANCE

Periodically check that all rack hardware and mounting bolts are properly torqued and secured to the bicycle frame. Periodically check for any loose fasteners or signs of cracking or failure and discontinue use if rack is damaged.

LIMITED 2-YEAR WARRANTY

MSW warrants this new MSW product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of MSW, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the MSW product and is not transferable.

In no event shall MSW be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the MSW product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended use with or compatible with MSW products

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

To initiate a warranty claim with any MSW product, please return the product to the original place of purchase, accompanied by a sales receipt. Reach out to info@mswbike with any questions.