

Thanks you for your purchase! At MSW we believe that having essential accessories makes a good bike ride great. We hope our Bar-End Lights keep you visible to everyone on the road.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to: www.mswbike.com/safety.

COMPATIBILITY & INTENDED USE

MSW Bar-End Lights are intended for installation on any bike with handlebars having a 17.5 to 19mm internal diameter.

NOTE: Do not remove plastic battery dividers until you are ready to install your lights as they are motion activated. This will help prevent any unnecessary battery drain.

TOOLS REQUIRED

Small pry bar or flathead screwdriver for bar-end plug removal.

INSTALLATION

1. Remove the handlebar end cap from each side of your handlebar.
2. Reassemble LED light set and insert the support base completely in the handlebar. Make sure that the light cap fits snugly into the support base.
3. Discard plastic strip in battery area to activate your light's motion sensor. Insert light cap into the support base.

⚠ WARNING: If this product is removed, replace it with an appropriate handlebar plug, grip, or bar-end. Unprotected handlebar-ends may cause serious injury.

ONGOING MAINTENANCE

⚠ WARNING: Periodically make sure your Bar-End Lights are securely installed in your handlebars and are in proper working order with fresh batteries.

WARRANTY PROCESS

We will happily back up our products. If you and your shop think your MSW product is worthy of a warranty inspection, please return the product to the original place of purchase, accompanied by a sales receipt.

For complete warranty information, visit www.mswbike.com/safety/warranty.