

THANK YOU FOR PURCHASING MSW HANDLEBAR TAPE!

▲ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

COMPATIBILITY AND INTENDED USE

MSW Handlebar Tape has two rolls and is adequate for covering both sides of most common road bicycle handlebars.

TOOLS AND SUPPLIES

Scissors
Electrical tape
Isopropyl alcohol

INSTALLATION

1. Remove all old handlebar tape and clean the bar of any old adhesive or grease with isopropyl alcohol.
2. Make sure any brake or derailleur cables to be wrapped over are secured to the handlebar with electrical tape.
3. Turn the brake lever hoods inside out and apply the 3-1/2" strips of tape over the brake lever clamp bands.
4. Starting at the bottom of the handlebar, begin winding the tape toward the top of the handlebars. You should overlap the tape in a spiral pattern, pulling it taut as you go. To avoid ripping or breaking the tape, be careful not to stretch it excessively or pull it too tight.
5. Wrap the tape fully, then trim the tape where you desire. Wrap the adhesive finishing strips around the ends of the trimmed tape to secure it.
6. Pop the end plugs into the handlebar ends and flip the brake lever hoods back down over the tape.

ONGOING MAINTENANCE

Periodically check to make sure that the handlebar tape is secure to the handlebars. Loose handlebar tape should be rewrapped or replaced if it is ripped or unable to be safely rewrapped.

LIMITED 2-YEAR WARRANTY

MSW warrants this new MSW product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of MSW, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the MSW product and is not transferable.

In no event shall MSW be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended use with or compatible with MSW products.

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.