

ACCESSORY BRACKET INSTRUCTIONS

THANK YOU FOR PURCHASING AN MSW® ACCESSORY BRACKET.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to: www.mswbike.com/safety.

COMPATIBILITY AND INTENDED USE

The MSW Handlebar-Mount Accessory Bracket is designed to fit on bikes with flat handlebars up to 22.2mm in diameter. It will also allow you to mount a standard water bottle cage opposite the accessory bracket. Mount your bottle cage per the cage manufacturer's instructions.

TOOLS REQUIRED

3 and 4mm hex wrenches

INSTALLATION

1. Completely remove the 4mm hex bolt from the bracket and backplate so you can remove the backplate.
2. Hold the bracket against the handlebar in the approximate position you want, insert the tab of the back plate into the slot of the bracket, and thread in the 4mm hex bolt until finger tight.
3. Move the bracket to the desired position on the bar and use a 4mm hex wrench to tighten the hex bolt until snug and bracket will not freely move on the bar.

NOTE: Double check the final position with your accessory mounted to make sure it does not interfere with the cables on your bike. Make sure there is no interference through the handlebar's full range of motion.

ONGOING MAINTENANCE

Periodically wipe down your MSW Accessory Bracket with a damp cloth. Inspect the plastic for signs of cracking and hardware for signs of corrosion. If you find cracks or corrosion, please replace the bracket.

LIMITED 2-YEAR WARRANTY

MSW warrants this new MSW product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of MSW, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the MSW product and is not transferable.

In no event shall MSW be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the MSW product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended use with or compatible with MSW products

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.