

Thank you for your purchase!

▲ WARNING: Cycling can be dangerous. Bicycle products should be installed and serviced by a professional mechanic. Never modify your bicycle or accessories. Read and follow all product instructions and warnings including information on the manufacturer's website. Inspect your bicycle before every ride. Always wear a helmet.

For additional product and safety information go to:
www.mswbike.com/safety.

COMPATIBILITY

Check to make sure your saddle is compatible with your seatpost. If you are unsure check with your local retailer or a qualified bicycle mechanic.

INTENDED USE



MSW Saddles are intended for use on roads and paved trails as well as ASTM Condition 2 use. This includes smooth paved roads, unpaved and gravel roads, and trails with moderate grades where loss of contact with ground may occur but drops are less than 6" (15cm).

Not intended for mountain, BMX, cyclocross, or downhill use.

TOOLS AND SUPPLIES

Hex wrench (refer to seatpost manufacturer's installation instructions).

BEFORE INSTALLING YOUR NEW SADDLE

1. Inspect the seatpost clamp for sharp edges. Smooth any burrs or sharp edges using a file or sandpaper before installing the saddle.
2. Trial fit the saddle rails to the seatpost clamp to ensure the clamp does not deform the saddle rails. If the clamp deforms the saddle rails, do not proceed with the installation.

▲ WARNING: Do not alter the clamp or the saddle rails to make it fit. Contact a bicycle mechanic or parts seller to obtain the correct seatpost clamp/saddle combination.

▲ WARNING: Failure to confirm saddle compatibility with the seatpost clamp or failure to properly install, torque, inspect and maintain the saddle and seatpost clamp can result in serious injury.

SADDLE INSTALLATION

1. Align the saddle rails with the channels in the seatpost clamp.
2. Adjust the saddle so it is centered front to back over seatpost clamp.
3. Adjust the saddle to a level or comfortable position.
4. Tighten the seatpost clamp bolts to the torque specifications listed in the seatpost User's Manual.

ONGOING MAINTENANCE

INSPECTION

Check the seatpost saddle clamp at regular intervals to make sure it has not loosened. Tighten when necessary.

Ensure there is no movement between the saddle rails and the saddle base. If you detect movement, stop using the saddle and contact your retailer.

Inspect the saddle at regular intervals, checking for scratches or gouges in the saddle body or rails. Scratch/gouge damage can weaken the saddle. Stop using the saddle immediately if you detect damage. Replace a damaged saddle before riding.

Check the saddle at regular intervals to ensure the saddle, rails and connections are intact. If you detect wear or breakage stop using the saddle and contact your retailer.

▲ WARNING: If a saddle has been in a crash or impact, even if there is no damage visible take it to your local retailer for inspection.

CLEANING

Wipe the saddle clean with mild soap and water. Do not use detergent, solvents or harsh chemicals, as they can damage the saddle.

If the saddle makes noise, clean it thoroughly and lubricate the connections between the saddle rails and the saddle body.

LIMITED 2-YEAR WARRANTY

MSW warrants this new MSW product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of MSW, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the MSW product and is not transferable.

In no event shall MSW be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the MSW product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended use with or compatible with MSW products

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

WARRANTY PROCESS

If you and your shop think your MSW product is worthy of a warranty inspection, please return the product to the original place of purchase, accompanied by a sales receipt.

For complete warranty information, visit www.mswbike.com/safety/warranty.