

**Thank you for your purchase!** At MSW® we believe having essential accessories makes a good bike ride great. This little magnet helps reveal the truth about your riding. Very impressive!

**⚠ WARNING: CYCLING CAN BE DANGEROUS.** BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

**⚠ WARNING: CHOKING HAZARD** - Small parts not for children under 3 years.

For additional product and safety information go to: [www.mswbike.com/safety](http://www.mswbike.com/safety).

### COMPATIBILITY AND INTENDED USE

The MSW Computer Spoke Magnet is compatible with magnet-activated cycling computers.

### INSTALLATION

1. Choose a spoke opposite the inner tube valve so the magnet acts as a counterweight.
2. Separate the magnet from its cradle.
3. Place the cradle behind a spoke, and thread the magnet into it from the front.
4. Move the magnet so it passes within the range of the computer sensor. Check with the manufacturer of the computer for optimal placement. Generally, for best results, the magnet should pass within 3 mm of the computer sensor.
5. Once you've verified that the sensor recognizes the passing magnet, tighten the two pieces of the magnet together so it cannot move freely when the wheel is spinning.

### ONGOING MAINTENANCE

Periodically check to make sure the magnet is secure.

### WARRANTY PROCESS

We will happily back up our products if there is a problem that is our fault! If you think your MSW product is worthy of a warranty inspection, please return the product to the original place of purchase, accompanied by a sales receipt. For complete warranty information, visit [www.mswbike.com/safety/warranty](http://www.mswbike.com/safety/warranty).